

## JACKSON SAFETY<sup>®</sup> V30 NEMESIS\*

Comfortable. Lightweight. Stylish

Stylish safety eyewear with a flexible frame, soft temples and nose bridge for added comfort to help improve worker compliance. Wrap-around design offer good coverage.

- Features a lightweight, wrap-around design, with flexible nylon frame for added comfort and coverage.
- Soft touch temples and nose bridge improving comfort and durability during periods of extended use.
- Clear polycarbonate lens, offers optical clarity and allows maximum visible light transmission.
- Anti-fog coating on clear lens to reduce condensation and counter the effect of sudden changes in temperature and humidity.
- Smoke mirror, polycarbonate lens to help reflect and reduce the amount of light and heat that passes through the lens when working outdoors, helping reduce eye strain and eye fatigue.
- Every pair includes a neck cord.
- AS/NZS 1337 certified with medium impact rating providing protection against mechanical hazards.
- 99.9% UVA/UVB protection reducing eye strain and protecting against UV radiation.



Performance  
safety eyewear with  
great comfort that  
helps drive worker  
compliance



### Area of Use:

Ideal eye protection for tasks that generate medium impact flying debris like chipping, scaling, grinding, machining metal, certain wood working operations<sup>1</sup>. Working in bright sunlight and glare.

<sup>1</sup> refer AS/NZS 1336:2014 Eye and Face Protection Guidelines

Description	Code	Lens	Case Contents
JACKSON SAFETY <sup>®</sup> V30 NEMESIS*	25679	Clear Anti-fog	1 pair/polybag, 12 pairs/carton
JACKSON SAFETY <sup>®</sup> V30 NEMESIS*	20380	Smoke mirror	1 pair/polybag, 12 pairs/carton



Exceptional  
Workplaces\*

**Guaranteed support:** The answer to the queries you may have on any of our products is just a phone call or email away.  
**Australia** 1800 647 814  
**New Zealand** 0800 447 814  
 Email [kcp.au@kcc.com](mailto:kcp.au@kcc.com) - [www.kcprofessional.com](http://www.kcprofessional.com)