



The Quidel Triage System

The Quidel Triage System is designed to provide results quickly and easily.

- Flexibility with customizable test panels via Test Select™ feature (option to select tests as required).
- Eliminate subjectivity of human interpretation with objective data on an automated test system, which may accelerate decision making near the patient.
- Faster time to results may contribute to faster patient disposition, reduced length of stay and increased ED throughput.

Quidel Triage System Product List

Product	Quantity	Cat. #
Tests and Controls		
Quidel Triage Cardiac Panel*	25 each	97000HSEU
Quidel Triage Profiler SOB™ Panel*	25 each	97300EU
Quidel Triage BNP Test*	25 each	98000XREU
Quidel Triage D-Dimer Test*	25 each	98100EU
Quidel Triage Total 5 Control 1	5 vials (5x0.25 mL)	88753
Quidel Triage Total 5 Control 2	5 vials (5x0.25 mL)	88754
Quidel Triage Troponin I Test*	25 each	98600EU
Quidel Triage Cardio2 Panel*	25 each	97500EU
Quidel Triage Cardio3 Panel*	25 each	97400EU
Quidel Triage Total 3 Control 1*	5 vials (5x0.25 mL)	88733
Quidel Triage Total 3 Control 2*	5 vials (5x0.25 mL)	88734
Quidel Triage NT-proBNP Test	25 each	98700EU
Quidel Triage NT-proBNP Control 1*	5 vials (5x0.25 mL)	98713EU
Quidel Triage NT-proBNP Control 2*	5 vials (5x0.25 mL)	98714EU
Quidel Triage TOX Drug Screen*	25 each	94400EU
Quidel Triage TOX Drug Screen Control 1	5 vials (5x0.25 mL)	94413
Quidel Triage TOX Drug Screen Control 2	5 vials (5x0.25 mL)	94414
Instrument and Accessories		
Quidel Triage MeterPro	1 each	55071
Quidel Triage MeterPro Barcode Scanner	1 each	52142
Quidel Triage MeterPro Y-Adapter	1 each	52098
Quidel Triage Printer Paper	1 each	52031
Quidel Triage Supervisor Codechip	1 each	80035
Quidel Triage Census Data Management Software	Kit	55069

*Not available for sale in the U.S.

Lab Quality at POC Speed

- Results in about 15-20 minutes.
- Quality Controls built into the meter, software and test devices.
- Lot-specific assay calibration (via lot-specific CODE CHIP™ module)
- External QC material available for Total Quality Assurance.
- Operator ID and QC lockouts.
- Batch patient testing possible with multiple devices providing the test device is run within 30 minutes of sample addition.
- Whole blood, plasma or urine samples.

Simple Operation, Low Maintenance

- Requires no special expertise or extensive training.
- Barcode reader for patient and operator ID.
- No maintenance other than paper and battery replacement, and periodic external cleaning.
- Quantitative diagnostic panel results are displayed and printed in easy to read numbers and highlighted* when the result is above the Expected Value.
- Qualitative diagnostic panel results are displayed and printed as positive (POS) or negative (NEG), eliminating the need for interpretation of lines.

* except for D-Dimer

Connectivity via the Quidel Triage Census® Advanced Test Management (ATM) System

- Comprehensive solution for monitoring and managing Quidel Triage Systems, providing data reports, meter and operator control and QC analysis.
- Flexible interfacing module that can be used to communicate with third-party systems.



Automated. Calibrated. Connected.
Professional diagnostics at the point-of-care



The Quidel Triage System

Fast quantitative results in about 15-20 minutes*

The Quidel Triage MeterPro is utilized in thousands of healthcare facilities worldwide. A comprehensive test menu provides the diagnostic answers you need to make rapid, cost-effective treatment decisions at the point-of-care (POC).

*except for TOX Drug Screen

Cardiovascular

The Quidel Triage System may accelerate decision making for the most critical conditions including heart failure, acute coronary syndrome, myocardial infarction, and thromboembolic events.



Easy test procedure

1

Add patient sample using transfer pipette included in each kit.



2

Insert test device into Quidel Triage MeterPro.



3

Read results on screen, or press "Print" for a hard copy.



Quidel Triage TOX Drug Screen

A screening test that provides simultaneous qualitative determination of the presence of drug and/or the major metabolites above the threshold concentrations of up to 10 distinct drug classes (11 unique assays) in urine.

Threshold concentrations for drug assays

Acetaminophen/Paracetamol	APAP	5 µg/mL
Amphetamines	AMP	1000 ng/mL
Methamphetamines	mAMP	1000 ng/mL
Barbiturates	BAR	300 ng/mL
Benzodiazepines	BZO	300 ng/mL
Cocaine	COC	300 ng/mL
Methadone	MTD	300 ng/mL
Opiates	OPI	300 ng/mL
Phencyclidine	PCP	25 ng/mL
THC	THC	50 ng/mL
Tricyclic Antidepressants	TCA	1000 ng/mL

Measurable Range						
Test/Panel Device	Myoglobin	CK-MB	Troponin I	BNP	D-dimer	NT-proBNP
Quidel Triage Cardiac Panel	5-500 ng/mL	1.0-80 ng/mL	0.05-30 ng/mL			
Quidel Triage Profiler SOB™ Panel	5-500 ng/mL	1.0-80 ng/mL	0.05-30 ng/mL	5-5,000 pg/mL	100-5,000 ng/mL	
Quidel Triage Troponin I Test			0.01-10 ng/mL			
Quidel Triage Cardio2 Panel	0.01-10 ng/mL			5-5,000 pg/mL		
Quidel Triage Cardio3 Panel		1.0-80 ng/mL	0.01-10 ng/mL	5-5,000 pg/mL		
Quidel Triage BNP Test				5-5,000 pg/mL		
Quidel Triage NT-proBNP Test						20-35,000 pg/mL
Quidel Triage D-Dimer Test					100-5,000 ng/mL	

